

Versatrainer Assembly Instructions

1-800-2669-3539

- 1) Rotate extrusion to upright position.
- 2) Lift pivot arm until extrusion screw holes align.
- 3) Turn 3/8" x 4" bolt into bottom hole. (Bolt is preplaced in hole for you)
- 4) Place 3/8" x 3 1/4" bolt into top hole and tighten.
- 5) Tighten securely using enclosed allen wrench.

